

STURDY

L A D D E R I N C .

4209 – 17A STREET SE
CALGARY, AB, T2G 3X1
TEL: (403) 264-2934
FAX: (403) 264-2998
www.sturdyladder.com

PUMP JACK NET SYSTEM PART NO. 806



FOR USE WITH SP SERIES STAGE PLANKS

FALL PROTECTION NETTING MEETS AND EXCEEDS ANSI STANDARD A10.11 – 1989
Straps and buckles meet and exceed the required 22.2 kilonewtons of required tensile strength.

- Net is simply installed by wrapping straps up and over either the plank side rail, or around the round rung of the planks, and using the reverse tension buckle pull tight.
- Use of the net requires SP series Aluminum Planks to be used as the back bench, and the walk plank. Planks must be secured to the Pump jack and Work bench with chains provided on each of these components.
- In accordance with use of all Ladder and Scaffold Equipment, Inspection prior to use for damaged, worn, or weathered parts is recommended.